


PARAGON BIN STATION

Assembly Instructions



Register your Paragon bin station at
www.paragon-outdoor.com
for an extra 1 year of coverage!



Facebook Twitter Instagram @paragonoutdoorcompany

Paragon Outdoor LLC

Customer Service Contact Information: 1-877-782-4482
support@paragon-outdoor.com

Before the Installation

Paragon Outdoor's 4 Year Limited Warranty

Warranty Conditions

1. This warranty shall be valid only if the product is installed, cleaned, handled and maintained in accordance with Paragon Outdoor's written recommendations listed below.
2. Without derogating from the above, damage caused by use of force, incorrect handling, inappropriate use neglectful use or assembly or maintenance, accidents, impact from foreign objects, vandalism, pollutants, alteration, painting, connecting, gluing, sealing not in accordance with the user's manual, or damage resulting from cleaning with incompatible detergents and minor deviations of the product are not covered by this warranty.
3. This warranty does not apply to damage resulting from "force majeure", which includes but is not limited to, hail, storm, tornado, hurricane, blizzard, flood, or fire effects, beyond stated claims.
4. This warranty is void if structural parts and components used are not compatible with Paragon Outdoor's written recommendations.
5. This warranty applies to the original owner and registrant and is non-transferable.

Warranty Duration	Extended Warranty
4 years	+ 1 year

*Extended warranty is applied when product is registered on www.paragon-outdoor.com within 1 month of purchase.

Care and Cleaning

For all products:

1. After rinsing with water, wipe all surfaces dry.
2. After rain or snow, promptly remove all water, snow, leaves and debris from the top, gaps and drainage areas to prevent long-term water exposure.

Customer Service Contact

If you are experiencing any issues with the assembly of your new structure, please do not return – our expert customerservice team will help you with all questions for a smooth assembly process.

Email: support@paragon-outdoor.com

Call: +1 (877)782-4482

















Hours of Operation

Speak with an Expert Customer Service Agent: Monday – Friday: 8:00 am – 5:00 pm CST


Spare Part List

PREPARE ALL THE NECESSARY TOOLS

To assemble your new Paragon Outdoor product properly and safely, make sure you have the following tools and accessories on hand, as these are not included.


						Already included				
										
Protective gloves	Hammer	Tape measure	Box cutter	Hammer drill	Cordless screwdriver	Phillips bit	Wrench			
A1 X1	A2 X1	B1 X1	C1 X2							
										
D1 X1	E1 X1	E2 X1	F1 X2	FD1 X2						
										
G1 X2	H1 X1	Q1 X4	Q2 X4	Q3 X4	Q4 X2					
										
		Q5 X2	Q6 X2	Q7 X4						
										
Q8 X2	Q9-1 X2	Q9-2 X2	Q9-3 X2	Q9-4 X2	Q11 X2	Q12 X4	Q13 X2			
										
Q10 X4	Q14 X2	Q15 X2		Q16 X2	Q17 X2					
										
S1 X10	S2 X36	S3 X32	S4 X34	S5 X42						
										
M8X80	3.9X32	M5X16	M5X16	3.9X13						

Exploded Assembly Drawing




DIMENSIONS



Height	48"
Width	67"
Depth	41"
Capacity	Up to 2X96 US Gallons trash bins



1



Do not fully tighten any screws at this step until all screws are in position and make sure panels are aligned on the top.






2



S2 X14
3.9X32




Note the 'UP' mark on G1 and F1 to make sure they are in the right direction.




S2 X14
3.9X32



Q1 X4	Q9-2 X2	Q9-4 X2	Q11 X2	Q14 X2	S3 X8 M5X16	S4 X12 M5X16	S5 X8 3.9X13
-------	---------	---------	--------	--------	----------------	-----------------	-----------------





Q10 X4



S3 X16




M5X16





Install 2 screws for lid (E1) first, then 2 screws for back panel (C1).
Do NOT fully tighten any screws until all 8 screws are in position.


Q7 X4





Install the gas spring. complete Step 1 (lid assembly) first, then to Step 2 (side assembly).




Wrench



Q9-1 X2	Q9-1 X2	Q6 X2	Q15 X2	S3 X8 M5X16	S5 X12 3.9X13
					






Q12 X4



Q13 X2



S1 X10








M8X80

Q16 X2



This product is supposed to be installed on a level surface. If installed on a non-level surface, the door may not open or close smoothly.

In this case, you can adjust the height by placing rubber pads at the corner (purchased separately) until the product is level.






After leveling, expansion screws can be installed as needed.

5/16 Inch




Foundation concrete thickness shall be greater than 4"mm, drilling depth shall be 3"mm.

S5 X4



Q4 X2








Q5 X2







Q8 X2



S5 X18



Q17 X2





    @paragonoutdoorcompany

Paragon Outdoor LLC

Customer Service Contact Information: 1-877-782-4482
support@paragon-outdoor.com