









GZH3-1220-CN


Double Curtain Installation Manual







Paragon Group USA


Customer Service: (877) 782 4482 Email: cs-outdoors@paragongroupusa.com

NO.	DRAWING	QTY	NO.	DRAWING	QTY
46		4	50		1
47		8	51		1
48	 M4x15 mm	48 +4	52		1
49		120 +12			




2



46		4	48		48
47		8	49		120



X4
Insert Plastic hooks into Curtain rails.




X2







Place Curtain rails in between the Side Rail screws and install by Self-tapping screws as shown.

3

Hang Netting and Private curtains on the hooks.

50		1
----	---	---





WARRANTY:

Warranty covers damage due to manufacturing defects only. Warranty does not cover weather inflicted damage (Force Majeure) and/or damages caused by not following assembly instructions and adhering to warnings in manual.

ATTENTION: Roof profiles, roof panels and gables must be aligned properly during assembly to minimize any possibility of leaking.



Instagram Facebook @paragonoutdoorcompany

Paragon Group USA

Customer Service: (877) 782 4482 Email: cs-outdoors@paragongroupusa.com