


# Paragon Outdoor Aluminum Louvered Pergola 12'×20'

Assembly Instructions



Register your pergola at  
[www.paragon-outdoor.com](http://www.paragon-outdoor.com)  
for an extra **1 year** of coverage!



Instagram Facebook YouTube Pinterest @paragonoutdoorcompany

Paragon Group USA

Customer Service Contact Information: 1-877-782-4482  
[support@paragon-outdoor.com](mailto:support@paragon-outdoor.com)











# Paragon Outdoor Aluminum Louvered Pergola


## 12'x20'

Please read the following instructions completely before you begin assembly. Any errors made during installation are not covered by the product's warranty. If you have any questions during the installation process, please call us at **1-877-782-4482**.



### NECESSARY TOOLS AND SAFETY GEAR(NOT SUPPLIED)

Goggles & Gloves 	Ladder 	Pistol drill 	Spirit level 	Utility knife 
Helmet 	Tape measure 	Monkey wrench 		

### 2D&3D FOOTING MEASUREMENT



# 2D&3D FOOTING MEASUREMENT



# Paragon Outdoor's 4 Year Limited Warranty

Items Included in Warranty: PRGRT-1012GY, PRGRT-1214GY, PRGRT-1220GY

## Limited Warranty

Paragon Outdoor warrants to the original purchaser that all components and hardware in its products, under normal use and service conditions, will be free from defects in manufacturing and materials for a period of 4 years\* from the date of original retail purchase subject to the definitions, terms and conditions contained in this warranty. This warranty period covers all parts including aluminum, steel, hardware and accessories.

Paragon Outdoor will replace any defective part within the warranty period, at its discretion, if it is found to be defective of workmanship or materials. Paragon Outdoor may request photographs, videos, or physical return of the defective part for verification purposes.

## Warranty Conditions

1. This warranty shall be valid only if the product is installed, cleaned, handled and maintained in accordance with Paragon Outdoor's written recommendations listed below.
2. Without derogating from the above, damage caused by use of force, incorrect handling, inappropriate use, neglectful use or assembly or maintenance, accidents, impact from foreign objects, vandalism, pollutants, alteration, painting, connecting, gluing, sealing not in accordance with the user's manual, or damage resulting from cleaning with incompatible detergents and minor deviations of the product are not covered by this warranty.
3. This warranty does not apply to damage resulting from "force majeure", which includes but is not limited to, hail, storm, tornado, hurricane, blizzard, flood, or fire effects, beyond stated claims.
4. This warranty is void if structural parts and components used are not compatible with Paragon Outdoor's written recommendations.
5. This warranty applies to the original owner and registrant and is non-transferable.

Item #	Warranty Duration	Extended Warranty
PRGRT-1012GY, PRGRT-1214GY, PRGRT-1220GY	4 years	+ 1 year

\*Extended warranty is applied when product is registered on [www.paragon-outdoor.com](http://www.paragon-outdoor.com) within 1 month of purchase.

## Operation: Hard-Top Gazebos and Pergolas

1. These are four-season products, meaning that they may be left up year-round. However, any accumulation of snow must always be removed from the roof of the unit.
2. The unit must be anchored using the appropriate hardware based on the flooring in which it is being anchored to.
3. Check all hardware for tightness before and during usage of the unit. Tighten screws at least twice a year.
4. The maximum weight allowance for an accessory attached to the center beam is 40 lbs.
5. If your product allows it, remove any mosquito netting and curtains during the winter months.

## Planning Assembly

1. It is the consumer's responsibility to comply with building rules, regulations, zoning restrictions or any other regional restrictions and obtain the required permits before purchasing the product and installing it.
2. Make sure that every part is in the box before beginning installation.
3. Some parts may have sharp edges; it is recommended to wear gloves, protective eyewear and closed shoes.
4. You must schedule enough time to complete assembly as you cannot leave the product unattended if it is not fully assembled, even if bolted to the ground.
5. A minimum of 3 people are required for a safe assembly of the product. This will vary depending on certain steps of installation.
6. Follow each instruction manual carefully to ensure the strength of the product.
7. To avoid damage to the product and its part, use the proper tools. Do not use the product as a support. The use of a ladder may be necessary at certain stages of assembly.
8. Keep the instruction manual and the parts list in case of future needs or references.
9. Do not assemble the product on days of wind or rain.

## Maintenance

For all products:

1. In case of a defective part or if a problem occurs while using this product, please contact Paragon Outdoor Customer Service at **(877) 782-4482**.
2. To order replacement parts, identify the model number and the part number found in your assembly manual.
3. Optional accessories may be available for your product such as mosquito nets, curtains, canopy replacements or more. Please contact your retailer for more information.

## Safety Information

**IT IS VERY IMPORTANT TO READ AND FOLLOW ALL SAFETY PRECAUTIONS BEFORE ASSEMBLY AND DURING USE OF THE PRODUCT.**

1. Keep children and pets away from assembly area.
2. When assembling and using the product, basic safety precautions must always be followed to reduce risks of personal injuries and damages to the product and its surroundings.
3. Ensure that all parts are in the boxes before starting the assembly. It is recommended to wear protective gloves since some of the parts have sharp edges.
4. Begin the assembly and install the product more than 10 ft. away from any obstructions including, but not limited to, a fence, overhanging branches, a laundry line or electrical wire and as much as possible in a place protected from the wind.
5. Always install the product on a level platform and be anchored according to the surface recommendations in the assembly instructions.
6. Check all hardware for tightness before and during the use of the product. Tighten screws at least twice a year.
7. Do not install the product in a space where there is a possibility of high winds.

## Care and Cleaning

For all products:

1. For cleaning: use a mild soap or soft detergent and wash with warm water using a sponge or fabric cloth. Rinse with clean water.
2. Snow must always be removed from the roof of the unit.

## Customer Service Contact

If you are experiencing any issues with the assembly of your new structure, please do not return – our expert customer service team will help you with all questions for a smooth assembly process.




Email: [support@paragon-outdoor.com](mailto:support@paragon-outdoor.com)



Call: +1 (877) 782-4482



## Hours of Operation



**Speak with an Expert Customer Service Agent:** Monday – Friday: 8:00 am – 5:00 pm CST  
We are available 24 hours a day, 7 days a week. Please allow up to 24 hours for a response.




## CARTON 1/6(POSTS AND LOOSE PARTS)

Reference	Parts	Quantity
A	 Post	2
A1	 Middle Post	2
A2	 Post	2






Reference	Parts	Quantity
Q1	 Post skirt	6
Q2	 Base plate	6



Reference	Parts	Quantity
Z3	 4mm Allen wrench	1
Z4	 4mm Hex bit	1





Reference	Parts	Quantity
Q15	 10×80 Expansion bolt	24
Q20	 6×35 Socket screw 6X35	24






Reference	Parts	Quantity
Z5	 6mm Allen wrench	1
Z6	 6mm Hex bit	1
Z7	 10mm Flat wrench	1

## CARTON 2/6(BEAMS)

Reference	Parts	Quantity
B	 Master Beam	2
C1	 Side Beam	2
C2	 Side Beam	2
D	 Middle Beam	1
E	 Middle Beam Cap	1

Reference	Parts	Quantity
F	 Connector Bar	4
H	 Crank Handle	1

Reference	Parts	Quantity
Q7	 Beam fixing screw	36
Q10	 Plastic cap	36
Q12	 Plastic cap	90
Q16	 Locking cap	4


Reference	Parts	Quantity
Q17	 Plug	88
Q18	 Washer	4
Q22	 6x12 Socket screw 6X12	4
Q23	 Ring cap	1
Q24	 Plastic latch	88












**Connecting Bar(F) & Brush Inside!**




## CARTON 3/6(LOUVERS)





Reference	Parts	Quantity
G	 Louver	12





Reference	Parts	Quantity
Q4	 Louver end cap A	22
Q5	 Louver end cap B	22
Q14	 5x6 Screw 5x6	184
Z1	 3mm Allen wrench	1
Z2	 3mm Hex bit	1

Reference	Parts	Quantity
Q6	 Spin for louver	45
Q13	 Rubber clog	46
Q16	 Screw 5x6	45
Q19	 6x35 Socket screw 6X35	45


## CARTON 4/6(LOUVERS )

Reference	Parts	Quantity
<b>G</b>	 Louver	<b>12</b>



Reference	Parts	Quantity
<b>Q3-1</b>	 Master louver end cap A	<b>1</b>
<b>Q3-2</b>	 Master louver end cap B	<b>1</b>
<b>Q4</b>	 Louver end cap A	<b>23</b>
<b>Q5</b>	 Louver end cap B	<b>23</b>

Reference	Parts	Quantity
<b>Q6</b>	 Spin for louver	<b>45</b>
<b>Q13</b>	 Rubber clog	<b>46</b>
<b>Q16</b>	 Screw 5x6	<b>45</b>
<b>Q19</b>	 6x35 Socket screw 6X35	<b>45</b>

## CARTON 5/6(LOUVERS )

Reference	Parts	Quantity
<b>G</b>	 Louver	<b>12</b>

## CARTON 6/6(LOUVERS )

Reference	Parts	Quantity
<b>G</b>	 Louver	<b>8</b>
<b>G1</b>	 Master louver	<b>2</b>

## ASSEMBLY GUIDELINES

STEP 1 : Assembly of Louvers


STEP 2 : Building the frame

STEP 3 :Louvers and their connections

# ASSEMBLY GUIDELINES

**Attention:**












Please note that the outlet on the skirt should be in the front position for the front side, while for the rear side, the outlet is a mirror image of the front face.








# STEP 1 Assembly of Louvers

## Components

Parts

G		44
G1		2
Q3-1		1
Q3-2		1
Q4		45
Q5		45
Q6		90
Q13		92
Q14		184
Q16		90
Q19		90


Tools

Z1		1
Z2		1
Z3		1
Z4		1
Z5		1

### Attention :



1. Master Louver G1 will be assembled with Q4/Q3-2 end caps and Master Louver G1 will be assembled with Q3-1/Q5. The Master Louvers will control the gear box within Beam D.
2. Louver G will be assembled with Q4/Q5 end caps (qty 44)




## STEP 1-1




Attention: Do not overtighten when assembling louver end caps. Q19 screw will not extend past Q16.

Assemble the louver connectors **Q4** and **Q5** as shown below.

**Q4x45**



**Q5x45**









# STEP 1-2





## Attention:

There are Qty 2- G1 Master Louvers each have different louver end caps installed. Install as shown below as these will attach to the gear box within Beam D and allow the louvers to open and close.

Attaching **Q3-1/Q3-2** (master louver end cap) and **Q4/Q5** (louver end cap) to **G1** (master louver) and **G** (louver). Use qty 2 of part **Q14**. Once attached, add **Q13** (rubber clog) to each hole at the end of louver. **Q3-1/Q3-2** are for master louvers and are pre-assembled already. Please identify **Q3-1/Q3-2** from end caps **Q4/Q5**.

















# STEP 2 Building the Frame





## Components

Parts

A		2
A1		2
A2		2
B		2
C1		2
C2		2
D		1
E		1

Q1		6	Q7		36
Q2		6	Q20		24


Tools

Z3		1	Z5		1
Z4		1	Z6		1


### Attention:




1. You can change the direction of the louvers by changing the direction of Middle Beam D.
2. Do not attach D (Middle Beam) to C until all louvers P are installed.
3. Check with hex wrench




## STEP 2-1



1. Slide **Q1** (post skirt) onto **A & A2**(post). Make sure to align notch on **Q1** with **A & A2**(post), as this is a drain outlet.




2. Use **Q20**(socket screw 6x35) to install **Q2**(base plate) to attach **A** (post). Use **Z4**(4mm bit ) to secure.




3. Tighten the screw with **Z3** if needed.

## STEP 2-2




Set **E** ( middle beam cap) aside as it will be installed in later step (**step 3-7**)

## STEP 2-2




Set **E** ( middle beam cap) aside as it will be installed in later step (**step 3-8**)

## STEP 2-3



Place the **A** (post) and **B** (side beam) on a flat surface. Use a square to make sure Beam **B**/Post **A** are properly aligned before tightening.



Insert **Q7** (beam fixing screw ) into **B** (master beam) attaching **A** (post). Use **Z6** to secure.





Suggestion:  
Please exercise caution when placing aluminum profiles on the ground to avoid scratches.

## STEP 2-4




### Attention:

Install C1/C2 to one side and securing to Post A and Mid Post A1. Before tightening Screw Q7 make sure beams and posts are properly aligned by using a square. Repeat to install opposite side.




1. Insert **Q7** (beam fixing screw ) into **C1/C2** (side beam) attaching **A** (post). Use **Z6** to secure.




2. Use **Q7** ( Beam fixing screw ) and place in **C1/C2** (side beam) to connect **C1/C2** to **A1**, tighten with **Z6** (6mm bit) included.

## STEP 2-5



1. Measure diagonally to ensure frame is square before setting **D** (middle beam) in center of **C** (beam).












2. In this step you will set **D** (beam) in place only. Do not secure connectors on beam **D** to outer beam **C1** & **C2**. This will be done in a later step (3-7).



# STEP 3 Installing Louvers


## Components

Parts


E		1
F		4
H		1
Q10		36
Q12		90
Q15		16
Q17		88
Q18		4
Q22		4

Tools

Z3		1
Z4		1



**Attention:**  
Please follow the order outlined in the instruction manual when assembling louvers.




## STEP 3-1




Attention: Position of louvers are important.  
Position Louver G1 with end caps Q4 and Q5 to outside beams B.


G1 Louver side with end caps Q3-1 and Q3-2 will insert into Middle Beam D, where the gear boxes are located.



1. Place **Q4** (louver end cap) on notch of beam this will allow room to insert **Q3-2** (louver end cap) into **D** beam where controller is located.





2. Move the **D** (middle beam) appropriately, put the **Q3-2** (Master louver end cap B) side into the gearbox.




3. Repeat the process and install the others piece of **G1**.



## STEP 3-2



**Attention:**  
 Install louvers from the other side of the pergola to get the frame steady.








1. Install Louver **G** at furthest end of pergola. Insert louver **G** end cap **Q4/Q5** into Middle beam **D**. Once in place install **Q12** (plastic cap) above where louver end caps **Q4/Q5** set into Beams **D**.



2. Insert louver **G** end cap **Q5/Q4** into outside Beam **B**. Once in place install **Q12** (plastic cap) above where louver end caps **Q4/Q5** set into Beams **B**.





## STEP 3-3



After installing the first 3 louvers, start connecting F (connection bar) to louver end caps. As you install the remaining louvers connect F to each louver end cap as each one is installed.


Pay attention to the direction of the F (connector bar) shown in above pictures. Use Q18 washer and Q16 connector main louver. Use Q17 washer and Q24 plug to attach connector bar F to louver end caps inserted into Middle Beam D. Lay Louver flat and install plastic cap Q12 in hole above louver end caps on Beam D.

## STEP 3-4




Connect F to louver end caps Q4/Q5 that are inserted in Outside Beam B. Use Q18 washer and Q16 connector main louver. Use Q17 washer and Q24 lug to attach connector bar F to louver end caps inserted into Beam B.


## STEP 3-5



## STEP 3-6





**Attention:** Louvers should be vertical




Keep louvers vertical to access the corner area and insert **Q10** plastic cap to cover holes in Beams **B/C**.

## STEP 3-7





**Attention :**  
 Louvers can rotate. Make sure to keep Middle beam centered on Beam C.





Use Z4 (4mm bit) to attach Q22 (socket screw) to connector in middle beam D securing to side beam C .

## STEP 3-8




**Attention:**  
 Place E (cap beam) onto Middle Beam D.  
 Gently tap into place to connect.

## STEP 3-9




Install Crank handles H to gear box

## STEP 3-10




## STEP 3-10



Check all dimensions of the pergola, then anchor base plate **Q2** to concrete foundation using **Q15** (expansion bolt). Caution the post skirting can scratch post.


## STEP 3-11



Insert **Q23** (ring cap) to Middle Beam **D**.





    @paragonoutdoorcompany

## Paragon Group USA

Customer Service Contact Information: 1-877-782-4482  
[support@paragon-outdoor.com](mailto:support@paragon-outdoor.com)